



Crane Scale User Manual



Soluciones de pesaje y
equipos para alimentos



CE

Model: OCS-S

Manual usuario BBG ref SL

1. First load: LOAD1 must larger than 20% capacity, and LOAD1<LOAD2<LOAD3, at the same time, between LOAD1 and LOAD2, LOAD2 and LOAD3, the interval Must bigger than 20% capacity
2. If balance of any point load is less than 20% capacity, after this point load calibration Finish, the scale will end calibration progress automatically and return.

CHAPTER 5 DISPLAY ILLUSTRATION

DISPLAY	ILLUSTRATION	REMARK
SETUP	Enter zero point calibration	
SCALE	Enter calibration	
CALSP	Enter parameter setting	
U Ad1	Enter voltage calibration	
LoAd1	First calibration point	LoAd1<LoAd2<LoAd3
LoAd2	Second calibration point	
LoAd3	Third calibration point	
-----	Exceed high limit	Tare weight can't exceed full capacity
-----	Exceed low limit	Tare weight can't be negative
-----	Waiting	
Err 10	Weight less than Min. Capacity	Can't accumulate the value
Err 11	Accumulated times overflow	Can't accumulate after 30times
Err 12	Accumulated weight overflow	Can't accumulate after 99999
Err 13	Error in repeat accumulation	Can't accumulate one weight repeatedly
Err 14	Calibration disable	Manual calibration selected
no***	Current accumulation times	
H****	Front four digit of accumulated Weight	Total weight= front four digit + rare four digit
L****	Rare four digit of accumulated weight	Total weight= front four digit + rare four digit
CLC	Ask if you really want to delete accumulated weight	In case error deletion
noCLC	Give up deletion	
88888	Confirm deletion	
SHI Ft	Switch	
---	Input value is too large	When you input tare or weight value
---	Input value is too small	When you input tare or weight value
noACC	No any accumulated content	When you check accumulation
-OL-	Overload warning	Tare + Net weight exceed full capacity + 9e
-LB-	Low battery warning	Turn off automatically one minute later
U ***	The voltage of current battery	
End	End	when parameter setting or calibration ready
OFF	Turn off	
UnStb	Input value before STB light on	

TABLE OF CONTENTS

CHAPTER 1 FEATURES AND SPECIFICATION	2
1. Features.....	2
2. Main technical data.....	2
3.Specification.....	3
4.Appearance illustration	3
5. Power supply.....	3
CHAPTER 2 DISPLAY	4
1. Led display.....	4
2. Statue lamp.....	4
3. Key.....	5
4. Remote control.....	5
CHAPTER 3 OPERATION GUIDE.....	6
1. Turn on/off	6
2. Zero	6
3. Tare	7
4. Hold	7
5. Accumulation	7
6. Accumulation search	7
7. Clear	7
8. Battery voltage check	7
9. Brightness	7
10. Zero show.....	7
11. Unit.....	7
CHAPTER 4 PARAMETER SETTING & CALIBRATION	8
1. Parameter setting	8
2. Calibration.....	10
CHAPTER 5 SIGNAL ILLUSTRATION	12
CHAPTER 6 TROUBLESHOOTING GUIDE	13

2. The capacity you choose relate to division, decimal position, below is detail list:

CAPACITY/DIVISION	FS (CAP)	Id (DIVISION)	Pt (DECIMAL POSITION)
1000kg/0.5kg	10	05	1
2000kg/1kg	02	01	0
3000kg/1kg	03	01	0
5000kg/2kg	05	02	0
10000kg/5kg	10	05	0
15000kg/5kg	15	05	0
20000kg/10kg	20	10	0


2. Calibration

◆ One point calibration program

OPERATION	DISPLAY	ILLUSTRATION
	00	Take Cap=5000kg scale as example. Pay attention that the screen display 0 after hanging tare weight, you can hang tare weight at first, then turn on.
Press【F1】and【F2】at same time 3seconds	P0000	Second digit flash, use function key to move digit, set value.
Press【TARE】ZERO【CLEAR】	P 1358	Input 1358, 1358 is calibration password
Press【SHIFT】	SCALE	Confirm, into calibration program
Press【SHIFT】	CALSP	No load, the screen display 0, and wait until STB light on.
Press【SHIFT】	Load f	Waiting load
Hanging standard weight 5000kg		Waiting until STB light on.
Press【SHIFT】	5000	Display capacity you choose when parameter Setting, and first digit flash. Waiting until STB light on.
Press【SHIFT】	----	Confirm
	-OL-	Calibration end
	50000	Display calibrated capacity , sometimes it display 4999.6,4999.8,5000.2,5000.4.
Press【TARE】	5000	Move decimal position
Put down weight	0	Check zero point, it displays 0, and STB light on
Hanging weight 5000kg again	5000	Below is test program to check scale accuracy.
Put down 5000kg weight and hang on 40kg weight	40	40kg is minimum capacity (20e), 50kg,100kg is also acceptable.
Put down 40kg weight, hang on 1000kg weight	1000	1000kg is 500e, check accuracy
Put down 1000kg weight	0	Check zero point

Generally, use one point calibration program, when you find scale linearity is not good, use three points calibration progress as below.

4.Appearance illustration



MODEL	A(mm)	B(mm)	C(mm)	H(mm)	N. W
OCS-1-S	65	340	37	460	13kg
OCS-2-S	65	340	37	460	13kg
OCS-3-S	90	340	45	520	16kg
OCS-5-S	110	360	55	630	26kg
OCS-10-S	120	360	65	770	41kg
OCS-15-S	135	360	95	880	63kg
OCS-20-S	165	360	95	900	69kg

5. Power supply

Battery: 6V/7Ah fully sealed Lead-Acid battery
Adapter: 9VDC/1000mA adapter

Current: the crane scale average current is about DC 100mA ± 10%, if battery charged, it can be used for about 50hours.

Low battery warning: When the lamp flashes, it means the battery needs to be recharged. The scale will power off automatically after 1 to 2 hours operation if the battery is not charged. Please recharge the battery before operating the scale again.

Charging method: Turn off the crane scale, use adapter in the carton, the lamp on the back cover will become orange when charging, and it will become red when the charging finish.

Generally, charging time should not less than 8hours, the crane scale have charging protection, long time charging can't damage the battery.

CHAPTER 4

PARAMETER SETTING & CALIBRATION

You can use remote controller to operate parameter setting and calibration
Key function

KEY	FUNCTION
【TARE】	Move digit(the digit choosed flash)
【ZERO】	Set value up
【CLEAR】	Set value down
【SHIFT】	Confirm, exit

1. Parameter setting

◆ TURN ON

OPERATION	DISPLAY	ILLUSTRATION
Press ON/OFF 3 seconds	88888	Display two times
	Ert	Display two times
	6000	New scale, the screen display 6000, if scale calibrated, the screen display capacity.
	U 6**	Display current battery voltage
	----	Wait stable
	0	Display zero point, generally "STB" light on

Generally, battery voltage should higher than **U 580**, lower than **U 680**, if the voltage lower than **U 580**, digits flash, the battery should recharge.

◆ PARAMETER SETTING

OPERATION	DISPLAY	ILLUSTRATION
Press F1 and F2 at same time 3seconds	P0000	Second digit flash, use function key to move digit, set value.
Press TARE 【ZERO】 CLEAR	P8088	Input 8088,8088 is parameter setting password
Press SHIFT	SETUP	Confirm, enter parameter setting program
Press TARE	FS-06	New scale, the screen display FS-06,if scale calibrated, the screen display capacity.
Press ZERO or CLEAR to choose	FS-05	Choose capacity, the screen display 02/03/05/06/10/15/20/30/50/60/75 circularly, take Cap=5000kg as example, choose FS-05
Press TARE confirm	Id-05	New scale, the screen display Id-05, if scale Calibrated, the screen display calibrated division. Choose division, the screen display 01/02/05/10/20 circularly. 5000kg scale division is 0.2kg, so choose Id=02
Press ZERO or CLEAR to choose	Id-02	New scale, the screen display Pt=0, if scale calibrated, the screen display calibrated decimal position
	Pt- 0	

4. REMOTE CONTROLLER




Press any key on the remote controller, the lamp on the controller will flash.

Key function:

1. **ZERO:**
 - a. In weighing status, When crane scale switch on with no load on the hook, but there are small digits on screen, press this key to obtain the zero reading.
 - b. In parameter setting and calibration process, it used for set value up.
2. **TARE:**
 - a. In weighing status, the function is equal to **TARE** key on overlay.
 - b. In parameter setting and calibration process, it used for move digit (the digit choosed flash).
3. **SHIFT:**
 - a. In weighing situation, used for function shift, or used with other key to more function.
 - b. In parameter setting and calibration process, it used for confirm setting.
4. **CLEAR**
 - a. In weighing situation, used for clear accumulation.
 - b. In parameter setting and calibration process, it used for set value down.
5. **ACCU**
It used for accumulation function, details see Chapter3-5.
6. **F1**
Function Key, used with F2 together, Press F1 solely, it will regulate brightness of LED.
7. **F2**
Function Key, used with F1 together.
8. **HOLD**
It used for hold function, details see Chapter3-4.
9. **OFF**
Turn off the crane scale.

SAFE OPERATION GUIDE:

1. The capacity of crane scale have been showed on the overlay. Don't make lifts beyond rated capacity of the crane scale.
2. Operators should not maneuver a loaded crane scale over personnel.
3. The scale must be routinely checked for operation. Don't operate if hook shackle, sling, cable, etc show any sign of defects or excessive wear.
4. If the scale is not going to be used for long time, recharging the battery every three months to preserve the life-span of the battery and recharge it before operation.
5. The battery charger is included in the scale package. Please use this charger. It's normal that the charger will become warm when the battery is charging.
6. Please note when the screen flash , it means that the battery needs to be recharged.



CHAPTER 6 TROUBLESHOOTING GUIDE

Trouble	Reason	Solution
No display when turn on	Battery damaged Battery contact loosed	Check battery Tighten the contact
Display flash	Low battery	Recharge the battery
Can't turn on & off	【OFF/ON】 key damaged	Check&clean the key
Can't tare	【TARE】 key damaged	Check&clean the key
Recharge indicator light can't turn on	The recharger damaged The recharger isn't plugged ready	Check the recharger Insert plug again
Display isn't stable	The load is unstable Loadcell cable damaged The scale in damp environment for a long time	Stabilize the load Check and replace loadcell Put the scale in dry environment
The display don't show "0" when empty load	No enough time for heating the scale after turn on	After turning on, heating 3-5 minutes
The error is large	The scale isn't hung properly	Check the scale and sling
Battery can't recharge	Battery damaged Outlet damaged	Replace battery Replace the outlet
Remote distance Shortened	Receiver window is too dirty low battery of controller	Check and clean Replace controller battery

CHAPTER 1

FEATURES AND SPECIFICATION

1. Features

- ◆ Multi-weighting units:
Kg., lb, N are selectable, generally kg are default unit.

◆ Multi-function operation:
Tare; Zero; Auto zero tracking; Total; Hold; Overload warning and record; Calibration through remote controller,etc functions.

◆ User-friendly design:

Cast aluminium housing for maximum protection; Large red 5 digit LED display (digit height 30mm); Safety factor up to 4 times capacity; Battery Operated with low battery indication; Automatic turn off , power-saving function.

2. Main technical data

Standard	According to OIML class III
Display	30mm (1.2") 5digits LCD/LED
Power on Zero Range	4% F.S.
Manual Zero Range	20% F.S.
Tare Range	100% F.S.
Stable Time	≤10 seconds
Overload Indication	100% F.S. + 9e
Max. Safety Load	125% F.S.
Ultimate Load	400% F.S.
Battery Life	≥70 hours
Battery Type	Fully sealed Lead-Acid battery, 6V/7Ah
Adapter	DC9V/ 1000mA
Operating Temp.	-10°C ~ +40°C(14° F ~ 104° F)
Operating Humidity	≤85% RH under 20°C
Remote Controller Distance	Min. 15m
Battery of Remote Controller	Battery: SIZE AAA, 1.5V x 2


3.Specification

MODEL	Max. Capacity (Kg)	Min. Weigh (Kg)	Division (Kg)	Total display counts (n)
OCS-1-S	1000	10	0.5	2000
OCS-2-S	2000	20	1	2000
OCS-3-S	3000	20	1	3000
OCS-5-S	5000	40	2	2500
OCS-10-S	10000	100	5	2000
OCS-15-S	15000	100	5	3000
OCS-20-S	20000	200	10	2000

◆ Three points calibration program

OPERATION	DISPLAY	ILLUSTRATION
	00	Take Cap=1000kg scale as example. Pay attention that the screen display 0 after hanging tare weight, you can hang tare weight at first, then turn on.
Press 【F1】 and 【F2】 at same time 3seconds	P0000	Second digit flash, use function key to move digit, set value.
Press【TARE】【ZERO】【CLEAR】	P1358	Input 1358, 1358 is calibration password
Press【SHIFT】	SCALE	Confirm, into calibration program
Press【SHIFT】	CALSP	No load, the screen display 0, and wait until STB and ZERO light on.
Press【SHIFT】	Load1	First load calibration
Hanging on first load 200kg		Suppose first load is 200kg, wait until STB light on.
Press【SHIFT】	10000	Display capacity, and first digit flash
Press【TARE】【ZERO】【CLEAR】	2000	Input 200kg, wait until STB light on.
Press【SHIFT】	----	
	Load2	Second load calibration
Hanging on second load 500kg		Suppose second load is 500kg, wait until STB light on.
Press【SHIFT】	04000	Display second minimum load, equal to first load plus 20% capacity, and first digit flash.
Press【TARE】【ZERO】【CLEAR】	05000	Input 500kg, wait until STB light on.
Press【SHIFT】	----	
	Load3	Third load calibration
Hanging on third load 1000kg		Suppose third load is 1000kg, wait until STB light on.
Press【SHIFT】	07000	Display third minimum load, equal to second load plus 20% capacity, and first digit flash.
Press【TARE】【ZERO】【CLEAR】	10000	Input 1000kg, wait until STB light on.
Press【SHIFT】	----	
	End	Calibration end
	00000	Display calibrated capacity , sometimes it display 999.90,999.95,0.00,05,000.10
Press【TARE】	10000	Move decimal position
Put down weight	00	Check zero point, it displays 0.0, and STB, ZERO light on.
Hanging on 1000kg weight again	10000	Below is test program to check scale accuracy.
Put down 1000kg weight, hang on 10kg weight	100	10kg is minimum cap (20e) , 20kg is also acceptable
Put down 10kg weight, hang on 250kg weight	2500	250kg is 500e, check accuracy
Put down 100kg weight	00	Check zero point

CHAPTER 2 DISPLAY



1. LED DISPLAY

30mm (1.2") 5digits LCD/LED

2. LAMP

- a. TARE: TARE lamp
- b. STB: STABLE lamp

3. KEY

a. ON/OFF

1. Press ON/OFF Key three seconds, the crane scale turn on
2. When turn on, Press ON/OFF Key three seconds, the crane scale turn off.

b. TARE

1. Hang sling or container on the hook, when the weight reading stable, press this key, the digits display "0", and TARE lamp switch on.
2. Put the goods into container, the scale will display goods net weight.
3. If move goods and container, the scale will display minus value of tare weight.

OPERATION	DISPLAY	ILLUSTRATION
Press 【ZERO】 or 【CLEAR】 to choose	Pt=0	Choose decimal position, the screen display 0/1/2/3 circularly, 0=xxxx.x, 1=xxx.x.x, 2=xxx.xx, 3=xx.xxx. Cap.5000kg scale choose Pt=0
Press 【TARE】 to confirm	Ab=24	Display zero range , A:zero range by hand;b:zero range automatically, 0-5 total 6 options: 0=0%F.S; 1=2%F.S;2=4%F.S;3=10%F.S;4=20%F.S;5=50%F.S. Generally. Don't change this parameter.
Press 【TARE】 to confirm	Cd=11	New scale, the screen display Cd=11, if scale calibrated, the screen display calibrated value.
Press 【ZERO】 or 【CLEAR】 to choose	Cd=11	C: zero-tracking range, 0-5 total 6 options; 0=0d; 1=0..5d; 2=1d; 3=1..5d; 4=2d; 5=2..5d d: display speed, 0-2 total 3 options; 0=slow; 1=average; 2=fast; before calibration, set Cd=0, after calibration, set Cd=11 again, generally choose Cd=11 when ex-stock..
Press 【TARE】 to confirm	LL=2	New scale, the screen display LL=2, if scale calibrated. the screen display calibrated value.
Press 【ZERO】 or 【CLEAR】 to choose	LL=1	LL: filter parameter, 0-5 total 6 options. from smallest to biggest, before calibration, set LL=0, after calibration, set LL=1 again, generally choose LL=1 when ex-stock.
Press 【TARE】 to confirm	Un=0	New scale, the screen display Un=0, if scale calibrated, the screen display calibrated unit.
Press 【ZERO】 or 【CLEAR】 to choose	Un=0	Choose unit, Un=0: kg, Un=1: lb, Un=2: other unit. Generally, choose Un=0 when ex-stock.
Press 【TARE】 to confirm	OFF1	New scale, the screen display OFF 1, if scale calibrated, the screen display calibrated value.
Press 【ZERO】 or 【CLEAR】 to choose	OFF2	Choose turn off method, 0-2 total 3 options; 0: turn off by hand; 1: if no operation, the screen Display [] after 15minutes to save power;2: if no operation, the screen display [] after 15minutes, and turn off automatically after 60minutes.Generally, choose OFF=2 when ex-stock.
Press 【SHIFT】	End	Confirm above parameter setting, Exit parameter setting program.

1. If you find mis-operation before end. Press 【TARE】 , the screen will display parameter setting circularly, correct error, if you find mis-operation after Parameter setting program end. you have to enter parameter setting program again to correct.

CHAPTER 3 OPERATION GUIDE

express key on scale front panel, express key on remote controller.

1. Turn on/off

◆ TURN ON

Press **[ON/OFF]** three seconds, the screen display as follows:

OPERATION	DISPLAY	ILLUSTRATION
[ON/OFF]	88888	Display two times
	ErL	Display two times
	10000	Display capacity
	U 6**	Display current battery voltage
	---	Waiting stable
	0	"STB" light on, you can weigh now

◆ TURN OFF

- 1 Press **[ON/OFF]** three seconds.
- 2 Press **[OFF]** three seconds.
- 3 Choose turn off method when parameter setting, the scale will Display **—** after no operation at 15minutes to save power, and it will turn off automatically after 60minutes.

2. Zero

	OPERATION	DISPLAY	ILLUSTRATION
1	Press [ZERO]	0	When scale turn on, generally scale Displays 0 if display small digits when no load, press this key.

3. Tare

◆ TARE DIRECTLY

	OPERATION	DISPLAY	ILLUSTRATION
1	Press [TARE]	0	After turn on, hanging tare weight such as sling, cable at first, press this key, "TARE" light on, then the scale will display net weight of the goods
2	Press [TARE]	0	

◆ SET TARE WEIGHT IN ADVANCE

OPERATION	DISPLAY	ILLUSTRATION
[SHIFT] [TARE]	00000	Current tare weight
[TARE]		Move digit, digit flash if choosed
[ZERO] or [CLEAR]	- ***	Set known tare weight
[SHIFT]	- ***	Exit, "TARE" light on, it displays minus tare weight, after hanging on goods, it will display net weight of goods.

4. Hold

OPERATION	DISPLAY	ILLUSTRATION
Press [HOLD]		Hold the weight reading
Press [HOLD]		Resume weight

5. Accumulation

OPERATION	DISPLAY	ILLUSTRATION
Press [ACCU]	no***	Current accumulation times
	H****	Rear four digits of total value
	L***	Front four digits of total value

After display above contents two times, the scale will return automatically, you also can press **[SHIFT]** to return.

6. Accumulation search

OPERATION	DISPLAY	ILLUSTRATION
[SHIFT] [ACCU]	no***	Current accumulation times
	****	Current weight reading
	H****	Rear four digits of total value
	L***	Front four digits of total value
	*****	Return

Press **[TARE]** and **[ZERO]** can forward or backward to check different times accumulation value or current weight value

7. Clear

OPERATION	DISPLAY	ILLUSTRATION
[CLEAR]	Clr	
[CLEAR]	noClr	Cancel clear
[SHIFT]	88888	Confirm clear

8. Battery voltage check

OPERATION	DISPLAY	ILLUSTRATION
[SHIFT] [F1]	U **	Display current battery voltage
[SHIFT]		Return

9. Brightness

OPERATION	ILLUSTRATION
[F1]	1~5 total 5 options, 1:darkness;5:brightness;(default value is 3)

10. Zero show

OPERATION	ILLUSTRATION
[SHIFT] [ZERO]	Display current zero point

11. Unit switch

OPERATION	ILLUSTRATION
[SHIFT] [HOLD]	Unit switch, Un=0, "kg" light on. Un=1, "lb" light on