

INSTRUCTION MANUAL

150KG Digital scale

MODEL:PL-150

Max Capacity:150KG,Min Capacity:0.5KG,precision0.1 kg

CONTENTS

DIGITAL SCALE,ABS COVER,2*CR2032 LITHIUM Cell

BATTERY INSTALLATION

NOTE:The included 2 batteries are for CR2032 LITHIUM Cell purposes only and should be replaced by consumer when needed.When changing batteries,adult supervision is recommended.We recommend using CR2032 LITHIUM Cell for best performance.Remove the bottom battery cover.Insert 2*CR2032 LITHIUM Cell in the polarity direction shown.Replace the batter cover.

USING YOUR DIGITAL SCALE

*.Remove the battery insulation gasket

*.Make sure the scale is static vertical state

*.First Press **ON/OFF** turn on Show 0.00KG.Second Press "**TARE**" Key,the scales is ready for use.

(Before weighing,Must Press **TARE** Key,this is very important)

*.You can weigh directyl on the scales or containers.However,if you choose to weigh on the containers,make sure the containers is in place before you turn the scale on.

*.Put the item you want to weigh on the hook The weight will be displayed on the LCD screen.

CHANGING BACKLIGHT

Press the **LIGHT** button to swith over.

USING THE TARE FUNCTION

Use this function any time you are going to use a container and wish to weigh the items only.Put the container on the hook.Press the **ON/OFF** button.Hold down the **TARE** button for a few seconds until a "O" is displayed on the LCD screen.Put the items you want to weigh in the container.The weight will be displayed on the LCD screen.

You can also weigh individual ingredients as you add them using the tare function

LCD DISPLAY DEFINITIONS

88888-Shown when you first turn your scale on.

0.00kg-Shown when the scale is ready to be used

OLD-Shown when there is an overload and excess weight needs to be removed from the hook

----E-Shown when the scale is underloaded.

AUTO SHUT OFF

The scale will automatically shut off after a minute of non-use

CARING FOR YOUR DIGITAL SCALE

Clean your with a damp cloth using water.Do not immerse in water or under running water.

Calibration

The first step: press and hold the **LIGHT** and the **TARE** key, insert a battery

The second step: press the **TARE** button, select the capacity 120KG

The third step: press the **ON/OFF** key, five digit code to display , and then press **ON/OFF** keyboard, ERL display a short time. 30KG display flash, 30kg hanging weights, and then show the 60KG, 60KG hanging weights, and then show the 120KG, hang 120KG weights. The emergence of PASS words, Calibration end.

BASCULA MARCA BBG REF: RDG150